




Spare Parts

Unique Single Seat Valve - Actuator for ATEX




ESE00701-EN4 2012-03

Original manual

The information herein is correct at the time of issue but may be subject to change without prior notice

1. Unique Single Seat Valve - Actuator for ATEX 4



Unique Single Seat Valve - Actuator for ATEX

Pos	Qty	Denomination	DN 25	DN 40	DN 50	DN 65	DN 80	DN 100
			25 mm	38 mm	51 mm	63.5 mm	76.1 mm	101.6 mm
Actuator								
		Actuator, complete (NO)	9613-1676-01	9613-1676-01	9613-1676-02	9613-1676-02	9613-1676-03	9613-1676-03
		Actuator, complete (NC)	9613-1676-04	9613-1676-04	9613-1676-05	9613-1676-05	9613-1676-06	9613-1676-06
		Actuator, complete (A/A)	9613-1676-25	9613-1676-25	9613-1676-26	9613-1676-26	9613-1676-27	9613-1676-27
5	1	Adapter, plastic	9613-1274-01	9613-1274-01	9613-1274-01	9613-1274-01	9613-1274-01	9613-1274-01
	1	Adapter, steel (Period 2009-2011)					9614-0653-01	9614-0653-01
6	□ 2	Bushing						
7	□ 2	O-ring						
8	□ 2	O-ring						
9	1	Plug	9613-4141-01	9613-4141-01	9613-4141-01	9613-4141-01	9613-4141-01	9613-4141-01
12	1	Air fitting	9611-99-1988	9611-99-1988	9611-99-1988	9611-99-1988	9611-99-1988	9611-99-1988
64	1	Ground wire	9613-4643-01	9613-4643-01	9613-4643-01	9613-4643-01	9613-4643-01	9613-4643-01
Yoke								
13	1	Yoke	9613-1330-01	9613-1330-01	9613-1331-01	9613-1332-01	9613-1333-01	9613-1334-01
17	3	Washer	9611-99-1888	9611-99-1888	9611-99-1888	9611-99-1888	9611-99-1888	9611-99-1888
18	3	Nut	9611-99-0360	9611-99-0360	9611-99-0360	9611-99-0360	9611-99-0360	9611-99-0360
			DN 25	DN 40	DN 50	DN 65	DN 80	DN 100
			25 mm	38 mm	51 mm	63.5 mm	76.1 mm	101.6 mm

Service kit for Actuator

□	Service kit	9611-92-6500	9611-92-6500	9611-92-6500	9611-92-6500	9611-92-6500	9611-92-6500	9611-92-6500
---	-------------------	--------------	--------------	--------------	--------------	--------------	--------------	--------------

Warning!

- ATEX Version only by use of genuine Alfa Laval parts.
- Never replace ATEX actuator with other types of Alfa Laval actuators.

Parts marked with □ are included in the service kits (actuator).

Recommended spare parts: Service kits.

TD 900-510

How to contact Alfa Laval

Contact details for all countries are continually updated on our website.

Please visit www.alfalaval.com to access the information directly.

© Alfa Laval Corporate AB

This document and its contents is owned by Alfa Laval Corporate AB and protected by laws governing intellectual property and thereto related rights. It is the responsibility of the user of this document to comply with all applicable intellectual property laws. Without limiting any rights related to this document, no part of this document may be copied, reproduced or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the expressed permission of Alfa Laval Corporate AB. Alfa Laval Corporate AB will enforce its rights related to this document to the fullest extent of the law, including the seeking of criminal prosecution.